


コンビネーションノブ COMBINATION KNOB

OKW

は標準在庫品ではありません



〈タイプA〉 $\phi 16$ SERIES



〈タイプA本体〉

■KNOB

(1個/1組)




コンビネーションノブ

Color	D		
Black	4	OKW-25 16 04 0	OKW-26 16 04 0
	6	OKW-25 16 06 0	OKW-26 16 06 0
Grey	4	OKW-25 16 04 8	OKW-26 16 04 8
	6	OKW-25 16 06 8	OKW-26 16 06 8


φ16 SERIES 〈タイプA本体〉

■WING KNOB

1個/1組




Color	□		
Black	4	OKW-27 16 04 0	OKW-28 16 04 0
	6	OKW-27 16 06 0	OKW-28 16 06 0
Grey	4	—	OKW-28 16 04 8
	6	OKW-27 16 06 8	OKW-28 16 06 8




〈タイプAアクセサリ〉

■CAP

1個/1組



Color	○	○
Black	OKW-41 16 00 0	OKW-41 16 10 0
Red	OKW-41 16 00 2	OKW-41 16 10 2
Yellow	OKW-41 16 00 4	OKW-41 16 10 4
Green	OKW-41 16 00 5	OKW-41 16 10 5
Blue	OKW-41 16 00 6	OKW-41 16 10 6
Light Grey	OKW-41 16 00 7	OKW-41 16 10 7
Grey	OKW-41 16 00 8	OKW-41 16 10 8




■NUT COVER

1個/1組



Color	○	○
Black	OKW-75 16 00 0	OKW-75 16 01 0
Grey	OKW-75 16 00 8	OKW-75 16 01 8




OKW

は標準在庫品ではありません

〈タイプA アクセサリ〉 ϕ 16 SERIES

bright ■ ARROW DISC



1個/1組



Color	
Black	OKW-42 16 00 0
Red	OKW-42 16 00 2
Grey	OKW-42 16 00 8

■ DISC



1個/1組



Color		
Black	OKW-73 16 00 0	OKW-73 16 01 0
Grey	OKW-73 16 00 8	OKW-73 16 01 8

bright ■ DIAL

1個/1組




OKW-44 16 01 0	OKW-44 16 02 0	OKW-44 16 03 9
OKW-44 16 04 9	OKW-44 16 05 9	OKW-44 16 06 0

Symbols silver

Collar	
透明	OKW-44 16 00 1

■ STATOR

1個/1組



OKW-60 16 01 9	OKW-60 16 09 9

Aluminium-sheet with adhesive foil

